



Glass Cleaner

A glass and surface cleaner with no scent that leaves no residues. Dissolves dirt on glass surfaces, mirrors, vinyl, plastic, Plexiglas, stainless steel, chrome, and counters.



Trigger sprayer included with 1 L

Directions

Dilute with unheated tap water according to the dilution rates listed below. Recommended for use with a squeegee. If not available, then spray evenly on surface to be cleaned and wipe off with lint free cloth or paper towel.

Recommended dilution rates:

Spray bottle (1 L) 1:16 (4 pumps)

1 L - Ready to use:

Ready to use, no dilution required.

Formats Available: 1 L & 4 L

Product Code: 57036, 57038