

RiteFlex

Handheld dispenser



Applications:

Install metering tip into cap and connect quarter turn end of tether to RiteFlex dispenser. Connect water supply hose of at least 3/8" ID to water inlet quick connect and push quick connect coupler onto inlet of RiteFlex dispenser. Depress trigger to begin dispensing desired concentrate solution; release trigger to stop flow of solution.

Benefits:

- Accurate dilution control built-in right into the portable unit, preventing any tampering with water to chemical ratios
- Safe chemical handling – eliminates leaks and chemical exposure
- Withstands harsh chemicals
- Eliminates measure and pour guesswork
- Easy to operate – One-handed operation
- Features a bucket clip and easy locking button
- Cost-effective versus wall-mounted system

Specifications:

| | |
|------------|-------------------|
| Tip Colour | (Various) |
| Flow Rate | 2.2 gpm |
| Operation | Manual dispensing |
| Material | Plastic |

Codes:

- **Product Code:** 51075 (Unit)
51074 (Tether Kit)

Available Dilutions:



1:10 1:20 1:40 1:64 1:80 1:120 1:256

